


R

RØROS HETTA



- EN** INSTALLATION MANUAL
- NO** INSTALLASJONSVEILEDNING
- DA** INSTALLATIONSVEJLEDNING
- SV** INSTALLATIONSANVISNINGAR






VISION



EN Warning! Before proceeding with installation, read the safety information in the User Manual.




NO Advarsel! Les sikkerhetsinstruksjonene i bruksveiledningen før apparatet installeres.

DA Advarsel! Læs sikkerhedsreglerne i brugsanvisningen inden installation.


SV Varning! Läs säkerhetsföreskrifterna i bruksanvisningen innan apparaten installeras.









1








2










3






4






5






6



7a





7b




4X






Max. Ø 6




4X




7b



8



9



10

